

Section 8 - Repair Parts List

8.1 Wheels and Casters

PT Transport For model SE50-175PT



1	SP-365	Caster-Swivel 8 x 3" Poly, Roller Bearing
2	SP-366	Wheel, 12" x 3" Poly, Roller Bearing

PL6 Transport For model SE50-175PL6

1	SP-297	Caster-Swivel 8" RB-Phenolic
2	SP-298	Caster-Rigid 8" RB-Phenolic
3	SP-531	Wheel Brakes


TW Transport For model SE50-175TW

1	SP-270	Caster-Swivel 12" x 3" MO, RT, RB
2	SP-270-1	Wheel, 12" x 3" Rubber, Roller Bearing, 3 1/2" Hub Length, 1" Axle
3	SP-270-2	Wheel, 16" x 3" Rubber, Roller Bearing, 3 1/4" Hub Length, 1" Axle



8.2 Pump Parts


For models SE50-175PT



1	SP-388	Vacuum Pump	9	SP-390	Flexible Coupling Spider
2	SP-446	Pressure Relief Valve, 1-1/4" x 1-1/2", 8 psi	10	SP-391	Flexible Coupling Body, 1-1/8" Bore
3	A220-277	Flexible Coupling, 2" Pipe	11	SP-394	Muffler, U5-1-1/2
4	SP-506	Vacuum Relief Valve, 1"	12	SP-195	Vacuum Pressure Gauge, 2-1/2" Back Mount
5	A220-278	SE50 Hood	13	SP-442	Muffler, 1", N10
6	SP-441	Muffler, 22070	14	SP-443	Pressure Relief Valve, 1"
7	A220-277	Flexible Coupling, 2" Pipe	15	A220-277	Flexible Coupling, 2" Pipe
8	SP-389	Flexible Coupling Body, 3/4" Bore			

8.3 VALVE AND FLOAT CONTROL PARTS ASSEMBLY

For Models: SE50-175PT, SE50-175TW, SE50-175PL6, SE50-175CB1




1	SP-444	4-Way Valve
2	A220-483	Float control Square Flange Gasket
3	A210-148	Float control Assembly, 1-1/4"

8.4 TANK COMPONENTS For Models: SE50-175PT, SE50-175TW, SE50-175PL6, SE50-175CB1



1	SP-104	Wing Nut, 1/2-13
2	A210-165	Cleanout Door Gasket

8.5 F50 FILTER COMPONENTS For Models: SE50-175PT, SE50-175TW, SE50-175PL6, SE50-175CB1



1	A-220-275	Filter Lid Assembly, F50
2	SP-386	Wing Nut, 5/8-11
3	SP-375	Disconnect Adapter, 2" Male Threads, F
4	SP-373	6" Security Chain
5	SP-374	Disconnect Cap, 2", V
6	A220-276	Pot Lid Gasket
7	A-220-274	Filter Lid Gasket F50
8	A220-336	Filter Sleeve, 5 cubic feet, Regular Weave F50
9	A220-583	Filter Sleeve, 5 cubic feet, Fine Weave, F50



8.6 TOOLS AND ACCESSORIES

For Models: SE50-175PT, SE50-175TW, SE50-175PL6, SE50-175CB1

1		A-210-965	STRAIGHT NOZZLE (FITS 2" HOSE)
2		A-220-151	FLARE NOZZLE (FITS 2" HOSE)
3		A-220-152	FLEXIBLE NOZZLE (FITS 2" HOSE)
4		A-220-562	NOZZLE VALVE, 1"
5		A-220-147	HOSE ASSEMBLY, 2" I.D. X 16' LONG, CLEAR
5		A-220-147R	HOSE ASSEMBLY, 2" I.D. X 16' LONG, RED
6		A-220-145	DISPENSING HOSE ASSEMBLY, CLEAR, 1-1/4" I.D. X 16' LONG
7		SP-262-BN2	GASKET FOR 2" DISCONNECT SET
8		SP-198-2	DISCONNECT COUPER, 2", FEMALE THREADS
9		A-220-624	FLOOR SQUEEGEE, 2"

